


Deer Fence End System Parts List

- A) 2¹/₂" Corner Post-1
- B) 1⁵/₈" Brace Posts-1
- C) 2ft. Corner Post Extension-1 **
- D) 1⁵/₈" Brace Cup-1
- E) 2¹/₂" Brace Band-1
- F) 2¹/₂" Post Cap-1
- G) 5/16" x 2" Carriage Bolt, Nut & Washer-1

Parts Not Shown:

- H) Self-tapping Screws - 2 **


** Only Included in 7.5/8 ft. Systems



Step 1: Dig a 36" hole. Adjust hole to allow for corner post to set out of hole with proper fence height. Place end post (part A) in hole and tamp or cement to secure post. Place 2ft. extension (part C) on top of post (Only for 7.5/8 ft Systems). Secure the extension w/ 2 self-tapping screws.




Step 2: Place brace band (part E) & cup (part D) over 2' end post extension (part C). Band should be approximately 12" from the top of the extension. Place 2 1/2" cap (part F) on top of the end post.



Step 3: Place brace post (part B) in brace cup. Place the other end of the brace post just inside your fence line (Fig. 1). Dig hole approximately 1' deep and either, cement at least 6" all the way around the post or use a dead man¹.

Fig. 1



Step 4: Tighten Bolts.

¹ **Dead Man**- A 4x4, solid cinder block, or even a large rock place perpendicular to the brace post end in the ground. (Fig. 2)

Fig.2

